



FIND WHAT YOU NEED, WHEN YOU NEED IT

USER MANUAL

TABLE OF CONTENTS

1.0 What is ORBIT?

Explanation Of The Product.....	Pg. 2
---------------------------------	-------

2.0 ORBIT App

2.1 How to Connect Your Orbit	Pg. 4
2.2 Find Your Orbit	Pg. 6
2.3 Find Your Phone	Pg. 6
2.4 Take A Selfie	Pg. 6
2.5 Settings	Pg. 7
2.6 Orbit Net	Pg. 9

3.0 Orbit Family

3.1 Orbit Keys	Pg. 10
3.2 Orbit Wallet	Pg. 12
3.3 Orbit Glasses	Pg. 14
3.4 Orbit Card	Pg. 16
3.5 Orbit Stick-On	Pg. 14
3.6 Orbit Powerbank	Pg. 18

4.0 SUPPORT	Pg. 22
-------------------	--------

5.0 IMPORTANT SAFETY WARNINGS

5.1 General Precautions	Pg. 22
5.2 Child Safety	Pg. 22
5.3 Safety Precautions	Pg. 22

6.0 REGULATORY NOTICES

6.1 North America	Pg. 23
6.2 European Union	Pg. 23

WHAT IS ORBIT?

Orbit is a family of Bluetooth trackers designed to help you find all your everyday items with ease via the free easy-to-use app (available on the App Store and Google Play). There is an Orbit for everything.

Make all your lost items ring. If your Orbit is within the 30m/100ft range, tapping the “Find” button on the Orbit App will make it ring. If you’ve lost your phone, press the button on your Orbit to make your phone ring, even if it’s on silent!

When you want a group photo but don’t have anyone to take the photo, Orbit is there for you. Open the in-app camera, place the phone in position and press the button on your Orbit to snap a selfie.

Keep the app running in the background, and the location of your Orbit will be saved. If your Orbit is out of range, check the map for the last seen location. Head to that area to search for your Orbit.

What do you need to do if your Orbit is lost? Mark it as lost and activate Orbit Net via the app. Every Orbit app is now searching for your lost Orbit. If someone walks past your Orbit, you will be notified of the location.



ORBIT APP

Download the Orbit App by heading to the App Store or Google play and download "ORBIT - Find your Keys, Find your Phone".



ORBIT



Open the app, and allow for the app to find your location. Please ensure bluetooth is turned on for the app to connect to your Orbit. You must create an account upon opening the app. Below is an overview of the App.

App Settings:

All Orbit app settings can be found here.

Your Orbits Location:


A marker on your map will show where your Orbit is (or was last seen).

Orbit Connection:

The green bars are an indication of your Orbits connection. More bars = Stronger Connection
Less bars = Weaker Connection

Add a new Orbit:

Tap the '+' icon to add a new Orbit. Make sure to rename your Orbits to keep track of them.



In-App Camera:

Using the Orbit as a selfie remote only works when using the In-App Camera. All photos taken will be saved to your usual photo gallery.

Battery:

Shows you how much charge your Orbit has left

More Options:

All settings specific to selected Orbit can be found here. Eg. Edit Orbit name, Separation Alarm, Delete/ Disconnect Orbit

Find Orbit:

To make your Orbit ring, tap the 'Find Orbit' button at the bottom of your screen.

Mobile Device Compatibility

ORBIT syncs with the following devices that support Bluetooth 4.0:

iOS

iPhone 5 or later

Android



Android 4.4 and above

HOW TO CONNECT YOUR ORBIT

Initially to activate your Orbit, follow the activation instructions on screen. You will then be prompted to create an account

After creating an account, you will be prompted to choose the Orbit product you wish to add. Follow the prompts to add.



After selecting your Orbit product, a new screen will appear with instructions on how to activate and connect your Orbit.



How to Rename your ORBIT


Tap the 'More Options' (3 Dots) on your device list which will bring up a new screen.

Tap on the edit icon to rename your Orbit. Here, you can also adjust all settings specific to the selected Orbit.



How to Delete an ORBIT device



In the event that you would like to delete an Orbit from your App, tap the 'More Options' (3 Dots) icon. In this section, you will find 'Delete this Orbit'. Tap the red icon to remove.



How to add Multiple ORBITs

Tap the '+' icon below your device list to add a new Orbit. You will be prompted to choose the Orbit product you wish to add.

Rename it (in the 'More Options' section) to keep track of which one is which. This will help when searching for your device. Select the Orbit you wish to find in your device list.




FIND YOUR ORBIT

All of the Orbit products work almost identical and can all be connected with the same app. Tap on the "FIND ORBIT" button at the bottom of the home screen. Your Orbit will ring if it's within range. If there is no ring, a notification will appear with the last known location of your Orbit.

FIND YOUR PHONE

Press the button twice on your Orbit, and your phone will ring and flash if it is within range. If there is no ring, the phone is out of range.



TAKE A SELFIE

Tap on the camera icon in the top right corner. Position or place your phone anywhere, get in the shot and click the battery button to take a photo. All photos will be stored in your gallery. Please note that this feature only works with the camera in the app.



SETTINGS

More Options

Tap on the More Options button (3 dots). All settings for your Orbit product can be found here. Settings for the Orbit app can be found in the App Settings menu.

Separation Alarm

Turning on the Separation Alarm allows for your Orbit and your phone to both ring when the devices step out of the 100ft/30metre radius to notify you that you have forgotten an item.

Safe Zone

If the Safe Zone feature is turned on, the Separation Alarm will not work when connected to WiFi. This feature is perfect for when you're at home around the house.

Orbit Sound



By tapping 'Find Orbit', your Orbit will ring. Select one of the three available alarms which suits you best.

Delete this Orbit

If you have mistakenly added an Orbit, tap the red icon next to 'DELETE THIS ORBIT'. This will disconnect the Orbit from your App. The Orbit can be reconnected by following the connection instructions.

Charge Reminder

This feature only applies to the Orbit wallet. Charge reminder uses your home WiFi connection to recognise when you are home. Once you return home (if your wallet battery is below 30%), a notification will be sent which will remind you to charge your Orbit Wallet.



App Settings

Tap on the settings icon in the top left corner to open the settings menu. All Orbit app settings can be found here. Settings for your Orbit product can be found in the More Options section.

Your Orbit Account

When you purchase your first Orbit, you will be prompted to create an account upon opening the app. Details about your account can be found in the App settings. By tapping 'Change Password' you will be prompted to change your Orbit account password. You will need this password to log in to your account.

Phone Alerts

These settings only affect the phone alerts when you use your Orbit to find your phone. Sound, vibration and flashlight alerts can all be turned on and off. Orbit ringtone settings can be changed in the More Options menu.

Ringtones

There are over 15 ringtone alarms to choose from. Select a melody that suits you. Select a different ringtone for different Orbits.

Help

The 'Help' section contains the Privacy Policy and Terms of Service. The Manual can also be found here.

Manual



Tapping 'Manual' will bring you to this manual. All information on Orbit products and the Orbit app can be found here.

Log Out

Tap the 'LOG OUT' button to log out of your Orbit account. You must be logged in to use your Orbit products and their features.

App Version

Below the 'LOG OUT' button in the settings menu, you will find the version of the app you are currently using.



ORBIT NET

What is the ORBIT NET



The Orbit Net is a community based anonymous search system which is always on the look out for your lost Orbit. What do you need to do if your Orbit is lost? Activate the Orbit Net and when someone (with the Orbit App installed) walks by your lost Orbit, you will receive a location update of where your item is located on a map. Use the Orbit App to guide you to the location and search for your missing Orbit. Invite your friends to download the App which will increase the chances of your Orbit being found (they do not need to have an Orbit to become a part of the Orbit Net).

How to use the ORBIT NET

When the Orbit App doesn't detect your Orbit, the 'Notify if found' button will pop up. By tapping it, you will be brought to the Orbit Net page. By tapping 'CONFIRM', your Orbit will be marked as lost and the Orbit Net will be activated. The entire Orbit community is now looking out for your lost Orbit.



Orbit Net Activated (Lost)

After activating Orbit net, Red (!) symbol appears



Orbit Net Activated (Found)

If found, Green Tick appears. Go to the location and search for your lost Orbit





ORBIT KEYS

Orbit Keys is a Bluetooth device designed to find your keys in seconds. Beautifully crafted from anodised aluminum, it's not only a handy gadget, but also a stylish accessory for your keys. Available in 12 stunning colours.



BLACK



SILVER



GOLD



ROSE GOLD



GUN METAL



DARK STORM



AZURE



SHOCKING PINK



EMERALD GREEN



VIOLET



SUNSET ORANGE



CANDY RED

FIND YOUR KEYS:

When in Bluetooth range (30m/100ft), press the "Find Orbit" button on the Orbit App. Your Orbit will play a melodic tune from the 90db in-built speaker. When out of range, the Orbit App will display the last known location of your keys on the map. Go to that location and search for your missing Orbit. Once back in range your Orbit will ring.


FIND YOUR PHONE:

To find your phone, press the button on the side of your Orbit. If in range, your phone will ring - even on silent!


TAKE A SELFIE:

Open the in-app camera and set it up ready for a photo. Step back and press the button on Orbit to snap the perfect selfie or group shot.


ORBIT KEYS




WHAT'S INCLUDED



ORBIT




Spare Battery



2x Battery Tool



Keychain



Keyring


INSTALLING/REPLACING THE BATTERY




1. To replace battery, enclose Orbit in between the 2 battery opening tools.




2. Twist the top battery opening tool anti-clockwise to open.



3. Open the Orbit and detach old battery from inside.



4. Place the new battery with the (+) symbol facing down.



5. Push the top and bottom Orbit shell together. Place the Orbit in between the opening tool. Twist clockwise to lock Orbit close.

FEATURES



Find Your Phone



Find Your Keys



Separation Alarm



Selfie Remote



Up To 6 Month Battery Life



Water Resistant



Replaceable Battery



Last Seen Location



Built-in Loudspeaker



Orbit Net Crowd Finding



ORBIT WALLET

Made from 100% genuine leather and sporting a 2500mAh rechargeable battery, you'll stay charged up on the go without sacrificing style and practicality. Best of all, no more forgetting to recharge your Orbit Wallet. If you arrive home and battery is running low on power, your phone will notify you to recharge it. The Orbit wallet also features a unique, leather-lined bill slot, 4 RFID blocking card slots and a receipt slot. Finished with folded edges and a classic simplistic design, this slim-line leather wallet will fit in your pocket with ease.



BLACK



BROWN



NAVY

FIND YOUR WALLET:

(30m/100ft), press the "Find Orbit" button on the Orbit App. Your Orbit will play a melodic tune from the in-built speaker. When out of range, the Orbit App will display the last known location of your powerbank on the map. Go to that location and search for your missing Orbit. Once back in range your Orbit will ring.


FIND YOUR PHONE:

To find your phone, press the button on your Orbit. If in range, your phone will ring - even on silent!


TAKE A SELFIE:

Open the in-app camera and set it up ready for a photo. Step back and press the button on your Orbit Wallet to snap the perfect selfie or group shot.

ORBIT WALLET



WHAT'S INCLUDED




ORBIT Wallet




Lightning Adapter

CHARGING THE BATTERY

Charging the battery on your Orbit Wallet is really easy. Simply plug the USB cord into a USB port (computer or wall charger) and wait until the 4 LED lights on your battery light up.



Charging your phone with the Orbit Wallet is even easier. Simply plug the Micro-USB or iPhone adapter cord into your phone.



FEATURES

- Find Your Phone
- Find Your Wallet
- Separation Alarm
- Selfie Remote
- Charge Reminder
- Micro-USB & iPhone Adapter
- Rechargeable 2500mAh Battery
- Last Seen Location
- Built-in Loudspeaker
- Orbit Net Crowd Finding



ORBIT GLASSES

The Orbit for glasses is the worlds smallest Bluetooth tracker. Stick it on the arm of your glasses and make it ring via the Orbit App. The Orbit for glasses will fit glasses with a (mininum size of) 4mm arm. The built-in rechargeable battery will last for up to 1 month and can be easily recharged using the included charge cable.



FIND YOUR GLASSES:

When in Bluetooth range (30m100ft), press the “Find Orbit” button on the Orbit App. Your Orbit will play a melodic tune from the in-built speaker. When out of range, the Orbit App will display the last known location of your glasses on the map. Go to that location and search for your missing Orbit. Once back in range your Orbit will ring.



Find your phone & take a selfie not available with Orbit Glasses


ORBIT GLASSES




What's Included



ORBIT Glasses



Charging Cable




Adhesive Strips

Recharging the Battery

To recharge, plug the included charger into a power source (USB slot) and connect the other end of charge cable to your Orbit Glasses. The LED will flash, indicating that charging is in progress. When the LED stops flashing and shows a solid light, charging is complete. Remove the charger and you're ready to go for another month.

*Orbit Glasses does not have to be removed to be charged



Features



Find Your Glasses



Separation Alarm



Rechargeable Battery



Last Seen Location



Up To 1 Month Battery Life



Built-in Speaker



Orbit Net Crowd Finding



ORBIT CARD

Orbit Card is the same size and thickness of a standard credit card, making it the worlds thinnest Bluetooth tracker. Slip it in your wallet amongst your credit cards and never lose your wallet again. The Orbit Card features a press button which allows you to find your phone and take a selfie remotely. The built-in rechargeable battery will last for up to 3 months and can be easily recharged using the included charge cable.

FIND YOUR WALLET:

When in Bluetooth range (30m/100ft), press the "Find Orbit" button on the Orbit App. Your Orbit will play a melodic tune from the in-built speaker. When out of range, the Orbit App will display the last known location of your wallet on the map. Go to that location and search for your missing Orbit. Once back in range your Orbit will ring.

FIND YOUR PHONE:

To find your phone, press the button on your Orbit. If in range, your phone will ring - event on silent!

TAKE A SELFIE:

Open the in-app camera and set it up ready for a photo. Step back and press the button on your Orbit to snap the perfect selfie or group shot.


ORBIT CARD



What's Included




ORBIT Card













Charging Cable

Recharging the Battery

To recharge, plug the included charger into a power source (USB slot) and connect the other end of charge cable to your Orbit Card. The LED will flash, indicating that charging is in progress. When the LED stops flashing and shows a solid light, charging is complete. Remove your card and you're ready to go for another 3 months.



Features

- | | | | |
|--|---|--|--|
|  Find Your Phone |  Find Your Wallet |  Separation Alarm |  Selfie Remote |
|  Up To 3 Month Battery Life |  Water Resistant |  Rechargeable Battery |  Last Seen Location |
|  Built-in Loudspeaker |  Orbit Net Crowd Finding | | |



ORBIT STICK-ON

Stick it, find it! The Orbit Stick-On is perfect for all those precious items you can't afford to lose. Stick it on anything! Remotes, laptops or anything else. A keyring attachment is included too, which adds to the list of things you can find with the Orbit Stick-On. Connect the keyring attachment to backpacks, luggage or instrument bags. Using the Orbit Stick-On, you can also make your phone ring and take a selfie remotely. The battery will last for up to a year before it must be replaced. Spare battery included.



BLACK



SILVER

STICK IT, FIND IT:

When in Bluetooth range (30m/100ft), press the "Find Orbit" button on the Orbit App. Your Orbit will play a melodic tune from the in-built speaker. When out of range, the Orbit App will display the last known location of your lost item on the map. Go to that location and search for your missing Orbit. Once back in range your Orbit will ring.


FIND YOUR PHONE:

To find your phone, press the button on your Orbit. If in range, your phone will ring - even on silent!

TAKE A SELFIE:

Open the in-app camera and set it up ready for a photo. Step back and press the button on your Orbit to snap the perfect selfie or group shot.


ORBIT STICK-ON




WHAT'S INCLUDED




ORBIT



Spare Battery




Keyring




Adhesive Strips


INSTALLING/REPLACING THE BATTERY



1. Move the tab to the 'OPEN' position.



2. Detach old battery from inside and place the new battery with the (+) symbol facing down.



3. Move the tab back over to the 'LOCK' position.

FEATURES



Find Your Phone



Find Your Orbit



Separation Alarm



Selfie Remote



Up To 1 Year Battery Life



Keyring Attachment



Replaceable Battery



Last Seen Location



Built-in Speaker



Orbit Net Crowd Finding



ORBIT POWERBANK

Orbit Powerbank can recharge all your devices with its 5000mAh battery. It also allows you to find it with the built-in Orbit. You can make your phone ring using your Orbit Powerbank to locate it or take a selfie remotely. Best of all, no more forgetting to recharge your Powerbank! If you arrive home and your powerbank is running low on power, your phone will notify you to recharge it. Available in 4 stunning colours.



BLACK



SILVER



ROSE GOLD



DARK STORM

FIND YOUR POWERBANK:

When in Bluetooth range (30m/100ft), press the "Find Orbit" button on the Orbit App. Your Orbit will play a melodic tune from the in-built speaker. When out of range, the Orbit App will display the last known location of your powerbank on the map. Go to that location and search for your missing Orbit. Once back in range your Orbit will ring.


FIND YOUR PHONE:

To find your phone, press the button on your Orbit. If in range, your phone will ring - even on silent!


TAKE A SELFIE:

Open the in-app camera and set it up ready for a photo. Step back and press the button on your Orbit to snap the perfect selfie or group shot.





ORBIT POWERBANK




Front View




Top View

-  USB Port
-  LED Indicator
-  Micro-USB
-  Orbit Button

WHAT'S INCLUDED




ORBIT Powerbank




Charging Cable

CHARGING THE BATTERY










Charging the battery on your Orbit Powerbank is really easy. Simply plug the USB cord into a USB port (computer or wall charger) and wait until the 4 LED lights on your battery light up.



Charging your phone with the Orbit Powerbank is even easier. Simply plug the Micro-USB or iPhone adapter cord into your phone.



FEATURES

- | | | | |
|---|---|--|--|
|  Find Your Phone |  Find Your Orbit |  Separation Alarm |  Selfie Remote |
|  Charge Reminder |  Orbit Net Crowd Finding |  Rechargeable Battery |  Last Seen Location |
|  Built-in Speaker | | | |

SUPPORT

Is my phone compatible with Orbit?

Orbit requires a phone to be running the Orbit app in the background. Bluetooth must be left on in the background (don't worry, our engineers have minimized the battery drain on your phone by leaving Bluetooth on). Orbit works with: iPhone 5 and later. and Android 4.4 or later. Bluetooth 4.0 or later is required.

How many Orbit devices can be paired to my phone or tablet?

Apple iOs devices can pair up to 6 Orbit devices at a time. Android devices can pair anywhere between 1-3 depending on the manufacturer and the operating system version.

Warranty Procedure

If you are having any issues with your Orbit, please don't hesitate to email us at help@hbutler.co and a team member will help resolve any issues you're having with the product.

Return Policy and Warranty

ORBIT has a Six Months Limited Warranty - for more information, visit: www.hbutler.co

Disposal and Recycling

Please kindly be aware that it is the consumer's responsibility to properly dispose and recycle ORBIT and accompanying components. Do not dispose of ORBIT with common household waste, the ORBIT unit is considered electronic waste and should be disposed of at your local electronic equipment collection facility. For more information, please contact your local electronic equipment waste management authority or the retailer where you bought the product. When discarding batteries, insulate the + and - faces of batteries with insulating or any kind of non-conductive tape. If improperly disposed, lithium batteries may short, causing them to become hot, burst or ignite.

IMPORTANT SAFETY WARNINGS

General Precautions

- ORBIT is not a toy
- Do not attempt to tamper with/modify/disassemble ORBIT
- Do not expose ORBIT to abrasive materials
- Do not place ORBIT near open flames
- Review ORBIT Specifications and other Information > Environmental Conditions and do not expose ORBIT beyond operating temperatures
- ORBIT's metal body conducts temperature effectively, avoid contact when left in extreme temperatures
- ORBIT's edges can be sharp, handle with care

Read, follow and keep this user manual and all safety instructions. Improper installation, use or disposal of ORBIT could be hazardous to your health and put others at risk.

Child Safety

ORBIT contains small parts, which can be a choking hazard. Please keep away from young children. If battery is swallowed, immediately seek medical help as serious injury may occur.

Battery Precautions

- Do not charge, short, disassemble, deform or heat batteries
- Do not throw batteries into fire
- Avoid mixed use of batteries, e.g. new, used or different types
- Keep batteries away from direct sunlight, high temperature and humidity
- Keep batteries out of reach of small children. Should a child swallow a battery, consult a physician immediately.

WARNING - Keep button batteries out of reach of children

- Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus.
- If you suspect your child has swallowed or inserted a button battery immediately call the 24-hour Poisons Information Centre on 13 11 26 for fast, expert advice.
- Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened. Do not use if compartment is not secure.
- Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous.
- Tell others about the risk associated with button batteries and how to keep their children safe.

For more information please visit: findorbit.com/help

REGULATORY NOTICES

North America

United States: Federal Communications Commissions [FCC]



FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

[1] This device may not cause harmful interference, and [2] this device must accept any interference received, including interference that may cause undesired operation.

INFORMATION TO USER:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the distance between the equipment and the receiver
- Connect the equipment to outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

WARNING:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

European Union

European Union: CE directive



WEEE:



STATEMENT:

Hereby, Global Shopping Network Pty Ltd, declares that Orbit is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The symbol on the product or its packaging signifies that this product has to be disposed separately from ordinary household wastes at its end of life. Please kindly be aware that this is your responsibility to dispose electronic equipment at recycling centers so as to help conserve natural resources. Each country in the European Union should have its collection centers for electrical and electronic equipment recycling.

For information about your recycling drop off point, please contact your local related electrical and electronic equipment waste management authority or the retailer where you bought the product.

- Do not dispose of the Orbit with household waste.
- Disposal of the packaging and your Orbit should be done in accordance with local regulations.
- Batteries are not to be disposed of in municipal waste stream and require separate collection.